



Application Guide:

PRO 2000 Chlorinated Rubber Paint

1. Overview

Ramuc PRO 2000 Chlorinated Rubber has been designed for commercial use where a competitively priced paint is required, and pool maintenance is performed every few years. For compatibility purposes, the existing paint on a previously painted surface should be determined before painting. If the existing surface is unknown, paint chips can be taken to any Ramuc distributor/dealer to be forwarded to the Ramuc laboratory for analysis.

Aged plaster should be checked for integrity. Check for hollow or weak/crumbling plaster by using a ball-peen hammer or any other comparable method. Perform repairs to the plaster before painting.

For VOC compliancy regulations, go to www.ramucpoolpaint.com

NOT RECOMMENDED FOR SPAS OR WHIRLPOOLS.

2. Supplies Needed

a. Cleaning Products:

Clean and Prep Solution by Ramuc, the complete surface preparation product to clean and etch surfaces prior to painting, and a 3500 minimum psi power washer.

Or use the traditional 3 step cleaning method -
Tri-sodium phosphate (TSP)
Muriatic or sulfamic acid solution
High-pressure (3500 p.s.i.) power washer

b. Condensation test material:

Several 2'x2' square pieces of transparent plastic
Duct tape

c. Painting supplies:

No thicker than 3/8" nap mohair or lambskin roller used for solvent based paints.
DO NOT use a cardboard cored roller.
Paint brush for detailing
5-gallon bucket for boxing (intermixing) paint

Mechanical mixer; a paddle attachment to a power drill
Ramuc Thinner or xylene for thinning paint if airless spraying, and cleaning-up tools and spills

d. **Joint or crack filler:**

Hydraulic cement or Vulkem 116 polyurethane sealant or any other submersible polyurethane sealant. Do not use silicone-based products, as paint adhesion will be adversely affected. Vulkem 116 must be top coated before being submersed in chemically treated water.

3. **General Surface Preparation**

Plaster or concrete surfaces should be tested for integrity and soundness. Pool paint is not a Band-Aid for weak surfaces. Power wash the surface to remove loose paint and dirt. Should any minor repairs need to be made, such as hydraulic cement patch or crack joint filling, do them at this time. Follow the manufacturer's recommendations. Prepare the surface thoroughly with **Clean and Prep Solution** by Ramuc, following the directions carefully. *This product takes the place of the TSP/ACID/TSP three-step process described as follows:*

Scrub the entire pool surface with a soap/tri-sodium phosphate (TSP) solution to remove all dirt, oils, and chalk. All surfaces should then be acid etched with a 15-20% solution of muriatic or sulfamic acid to remove mineral deposits and to achieve a medium sandpaper grade finish on bare concrete or plaster surfaces. Neutralize/rinse with TSP and water.

CONDENSATION TEST - After all cleaning is completed, allow the pool surface to dry. Average dry times vary regionally and are dependent upon the porosity of the surface. It is recommended to wait at least 5 dry days and then perform a condensation test to determine surface dryness.

- Tape 2' x 2' pieces of transparent plastic to areas in the deep end wall, floor and several other areas on the pool.
- Wait at least 4 hours to determine if condensation has formed under the plastic.
- If condensation is evident, the surface is not dry enough to paint.
- Remove the plastic and wait 24 hours to perform the test again and continue until no condensation forms. This insures the surface is dry enough to apply paint.

4. **Application**

Mixing the paint – PRO 2000 is self-priming; no other type of primer is recommended or should be used. Mechanically mix the paint to achieve uniform consistency and color. If more than one (1) gallon of paint is used at a time, to box (intermix) several gallons together. Use no thicker than a 3/8" nap mohair or lambskin roller used for solvent based paints. DO NOT use rollers with cardboard cores. Apply at the recommended coverage rate. **Ideal air temperatures for application are between 50°-90°F.** Surface temperature should be at least 50°F, no more than 90°F. Overnight curing temperatures MUST be at least 50° F.

Do not paint when rain is imminent. Use dark colors for accent painting only. Dark colors can prematurely fade or blister in chemically treated water.

5. Cure Rates

Outdoor pool: 5-7 dry days

If rain occurs during the curing process, allow an extra day of dry time for each day of rain. Rain or moisture or excessively high humidity can cause blistering, color blushing, and the finish could be affected.

Dry time to touch: 15 minutes

To recoat: 24 hours

Finish: Flat

Primer: All Ramuc paints are self-priming

Fill outdoor pools after at least 5 dry accumulative days

Not recommended on indoor pools.

6. Coverage

150-175 square foot on bare or rough surfaces.

250-300 square foot on previously painted chlorinated rubber pools.

(Actual coverage will vary and is dependent upon the texture and profile of the surface.)

Minimum dry film per coat: 1.0 mils dry (3.0 mils wet)

Maximum dry film per coat: 2.0 mils dry (6.1 mils wet)

Clean-up: Ramuc Thinner or xylene

7. Technical Data

Weight/gallon: 11 ± 0.2 lbs.

Solids by weight: 57% ± 1%

Solids by volume: 35% ± 1%

V.O.C.: does not exceed 575 g/l

Visit www.ramucpoolpaint.com for VOC compliance regulation updates.

8. Spray Information

Airless: 2000-2500 p.s.i.

Tip Size: .013-.017

9. Special Situations

Blushing-Fading-Chalking

The Cause:

- The pool is filled too soon (see cure rates) before the paint is completely cured, causing a blush over the surface which looks like fading or chalking.
- Super-chlorinated water may cause a bleached-out look.
- The shock of calcium hypochlorite can cause a white, bleached look to the paint film, leaving a whitish deposit.
- A chalky substance can be created by over treating the water with shock,

bromine, ozone and ionization, possibly causing the paint to break down. We suggest a natural polymer product or clarifier that can reduce the chalking problem.

- Iron in the water from rust in the filter system may leave deposits and stain the film.

The Solution:

- Scrub surface using a solution of soap and water. This will remove surface dirt and deposits.
- Wipe with a weak (2-3%) solution of muriatic acid. Acid will remove iron stains without damaging the paint film.
- Solvent wipe affected areas with Ramuc Thinner.
- Check your pool water chemistry daily or weekly for calcium hardness, total alkalinity, and balanced pH.
- Extremely corrosive water can ultimately cause deterioration or breakdown of a paint film over a period of years.
- Be sure the newly painted pool surface dries at least five dry, sunny days before filling.
- **Follow the manufacturer's recommendations for proper water chemistry.**

Blistering

The Cause:

- Using a nap roller thicker than 3/8" nap draws air into paint film.
- Applying paint too thick.
- Painting a damp surface.
- Painting in direct sunlight can cause vapor or (heat) blisters.
- Filling the pool before the paint is cured.
- Incompatible paints.

The Solution:

- Scrub off blisters; wipe lightly with RAMUC thinner. Apply a very thin coat of PRO 2000 to blend in for uniformity if needed.
- All painted surfaces must be dry prior to painting with PRO 2000. Perform the Condensation Test again.
- Paint must cure for 5 dry days on an outdoor pool.