



Lift Chair Installation

Description

Installation services for ADA and other style lift chairs.

Services Include

- Verification of chair size, type and style compliance for intended application.
- Verification of chair location to comply with ADA guidelines.
- Location and mounting of (3) or (4) mounting anchor and bolt style anchors.
- Core drill for anchors, and verify adequate concrete thickness.
- Install core-drilled bolt and receiver style anchors using structural epoxy.
- Connection to adequate existing bonding grid wire at anchor location.
- Allow structural epoxy to cure to cure, (usually 24 to 48 hours).

Options

- Additional specifications and charges will be required for different style anchor requirements, (such as removing, anchoring and re-pouring concrete).
- Installation of #8 bare copper bonding wire from anchor location to nearest accessible pool bonding grid access point, requiring cutting of concrete and filling with flex fill caulk over top of cut and buried wire after connection will incur additional fees.
- Additional concrete deck work required for installation, due to insufficient concrete depth, (usually 6" thick required).
- Placement and installation of lift chair on new anchors after cure, (optional based on cure time and job requirements).

Notes

- Facility owner, agent, or on-site management can install lift chair once epoxy is cured.
- No liability for materials specified or provided by others.
- Approved ADA compliance lift chairs and installation specifications differ per the manufacturer's directions.
- Installation assumes that adequate unobstructed access to and from the location exists.

Availability

- Available in all North and Central American markets.